

# ASSEMBLY INSTRUCTION

MODEL : HM 2211.01

DESCRIPTION : 3 DOORS SHOE CABINET

	SOFT DRY CLOTH	CHEMICAL	HEAT	KEEP DRY	HANDLE WITH CARE	DO NOT USE KNIFE

HARDWARE	A	B	C	D	E	F	G	H	I	J	K	L
	16MM C/S SCREW M3.5X14MM 1X44	38MM C/S SCREW M4X38MM 1X6	NAIL SR 1X23	L-KEY 1X1	SHELF SUPPORT 1X1E	ROUND PLASTIC LED 1X5	Z PIN STOPPER 1X2	HINGED SR 1X6	MIDFIX 625410046 6 SETS	GRABKIT C/P 1X6	HANDLE 5072 1X3	22MM HANDLE SCREW MAX2MM 1X3

