PLEASE FOLLOW EXAMPLE: STEP ASM. HARDWARE PART **THOSE NUMBERS AS** MODEL: HM2268 **MODEL SIZE: H740 x W1200 x D595** 12 STATED BELOW FOR (A)EASY ASSEMBLE.  $(\mathbf{A})$ **B**) **(c**) **E**)  $(\mathbf{F})$  $\bigcirc$ 2 3 JCBC HARDWARE 40mm 25mm x12 16mm 96mm PART x1 x46 x11 **x8 x1 x1 x**1 х3 x1 х1  $(\mathbf{M})$  $(\mathbf{G})$  $(\mathbf{H})$ (K)7 8 9 10 30mm **x6 x6 x6** x1 set х4 x12 **x6 x1** x1 **x2** хЗ хЗ 3  $(\mathbf{F})$ (M) x2 (H)<sub>x6</sub> 1st 3 STEP D x2 5 9 10 (D) x2 4 (E) 2 REPEAT SAME STEP 3 TIMES 4 2nd E STEP 5 6 (A)x3B 1 2 6 Complete (K) x4 2 3 (C)x4 **⋰**(G)x6\ A)x3 (C) x24.